

SPARE PARTS LIST

PAGE 1

MODEL NO. HR2810

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	286263-4	CAP 35	1	
002	233940-9	RING SPRING 19	1	
003	417629-9	CHUCK COVER	1	
004	257241-1	RING 21	1	
005	345187-4	GUIDE WASHER	1	
006	233916-6	CONICAL COMP. SPRING 21-29	1	
007	922241-7	HEX. SOCKET HEAD BOLT M5X25	4	
008	158057-6	GRIP 36 COMPLETE	1	
009	921919-9	HEX. BOLT M8X110	1	
010	419975-6	GRIP BASE 20	1	
011	158288-7	BARREL COMPLETE	1	
012	267354-0	FLAT WASHER 31	1	
013	262133-1	URETHANE RING 31	1	
014	267354-0	FLAT WASHER 31	1	
015	234020-4	COMPRESSION SPRING 37	1	
016	419986-1	LOCK SLEEVE	1	
017	233952-2	RING SPRING 41	1	
018	213620-3	O RING 46	1	
019	922128-3	HEX. SOCKET HEAD BOLT M4X16	1	
020	419984-5	CRANK HOUSING COVER	1	
021	216022-2	STEEL BALL 7.0	1	
022	158285-3	TOOL HOLDER COMPLETE	1	
023	213344-1	OIL SEAL 9	1	
024	961140-8	RETAINING RING	1	
025	331769-8	SLEEVE 9	1	
026	324669-9	IMPACT BOLT	1	
027	324402-9	RING 10	1	
028	421955-0	CUSHION RING 13	1	
029	324216-6	O RING CASE	1	
030	213073-6	O RING 9	1	
031	233917-4	RING SPRING 28	1	
032	267105-1	FLAT WASHER 29	1	
033	234021-2	COMPRESSION SPRING 30	1	
034	331770-3	DRIVING SLEEVE	1	
035	213435-8	O RING 26	1	
036	256099-5	PIN 6	1	
037	324733-6	STRIKER	1	
038	213227-5	O RING 16	1	
039	331776-1	PISTON CYLINDER	1	
040	233954-8	RING SPRING 21	1	
041	158282-9	CONNECTING ROD COMPLETE	1	
042	227532-4	SPIRAL BEVEL GEAR 31	1	
043	266420-0	TAPPING SCREW 5X20	4	
044	234019-9	COMPRESSION SPRING 4	1	
045	345814-3	LINK PLATE	1	
046	345815-1	GUIDE PLATE	1	
047	911118-1	PAN HEAD SCREW M4X12	1	
048	213262-3	O RING 18	1	
049	162256-4	LINK LEVER COMPLETE	1	
050	419988-7	FILTER CAP	1	
051	213218-6	O RING 16	1	
052	443129-3	FILTER	1	
053	419987-9	CRANK CAP	1	
054	213406-5	O RING 30	1	
055	158289-5	CRANK HOUSING COMPLETE	1	
056	324793-8	CRANK SHAFT	1	
057	211232-6	BALL BEARING 6002LLU	1	
058	961055-9	RETAINING RING S-15	1	
059	233951-4	C. C. SPRING 16-26	1	
060	223167-9	CLUTCH	1	
061	226653-9	HELICAL GEAR 29	1	

SPARE PARTS LIST

PAGE 2

MODEL NO. HR2810

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
062	267353-2	FLAT WASHER 8	1	
063	961034-7	RETAINING RING	1	
064	345818-5	CUP WASHER 16	1	
065	254239-9	KEY 4	2	
066	227524-3	SPIRAL BEVEL GEAR 9	1	
067	254239-9	KEY 4	1	
068	210105-0	BALL BEARING 6001LLU	1	
069	125386-2	TORQUE LIMITTER ASS'Y	1	
070	961006-2	RETAINING RING S-10	1	
071	210024-0	BALL BEARING 608LLU	1	
072	424028-8	SEAL RING	1	
073	158287-9	GEAR HOUSING COMPLETE	1	
074	213445-5	O-RING 26	1	
075	213133-4	OIL SEAL 12	1	
076	331775-3	SLEEVE 10	1	
077	210054-1	BALL BEARING 6000LLU	1	
078	253171-4	FLAT WASHER 10	1	
079	240095-3	FAN 64	1	
080	515293-1	ARMATURE ASS'Y 220V INC. 79,82,83	1	
081	266325-4	TAPPING SCREW 4X70	2	
082	210023-2	BALL BEARING 627DDW	1	
083	681656-4	INSULATION WASHER	1	
084	419989-5	BUFFLE PLATE	1	
085	526583-7	FIELD ASS'Y 220V	1	
086	419981-1	MOTOR HOUSING	1	
087	643766-5	BRUSH HOLDER	2	
088	266421-8	TAPPING SCREW 3X10	2	
089	194074-2	CARBON BRUSH CB-325	1	
091	419983-7	REAR COVER	1	
092	266326-2	TAPPING SCREW 4X18	2	
093	638565-8	LEAD UNIT	1	
094	638567-4	LEAD UNIT	1	
095	638566-6	LEAD UNIT	1	
096	266326-2	TAPPING SCREW 4X18	1	
097	158284-5	CHANGE LEVER COMPLETE	1	
101	419976-4	HANDLE	1	
102	911258-5	PAN HEAD SCREW M5X35	2	
103	266420-0	TAPPING SCREW 5X20	2	
104	863914-2	HR2810 NAME PLATE	1	
105	419992-6	F/R CHANGE LEVER	1	
110	419990-0	SWITCH LEVER	1	
111	158281-1	SWITCH HOLDER COMPLETE	1	
112	650591-7	SWITCH	1	
113	419980-3	HANDLE COVER	1	
114	266326-2	TAPPING SCREW 4X18	1	
115	691015-4	POWER SUPPLY CORD 0.75-2-2.5	1	
116	682573-1	CORD GUARD 10	1	
117	266326-2	TAPPING SCREW 4X18	1	
118	687169-3	STRAIN RELIEF	1	
120	819355-0	CLEAR LABEL	1	
A01	324219-0	DEPTH GAUGE	1	
A02	824789-4	PLASTIC CARRYING CASE	1	
A03	805761-5	HR2810 PLASTIC CASE LABEL	1	

SERVICE DRAWING

PAGE 1

MODEL NO. HR2810

