

SPARE PARTS LIST

PAGE 1

MODEL NO. SP6000

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	210013-5	BALL BEARING 698VV	1	
002	681634-4	INSULATION WASHER	1	
003	513678-5	ARMATURE ASS'Y 220-240V INC. 1,2,4-6	1	
004	240091-1	FAN 60	1	
005	345767-6	DRUM	1	
006	211131-2	BALL BEARING 6001DDW	1	
007	345742-2	SHAFT LOCK	1	
008	265011-4	+ BINDING HEAD SCREW M5	1	
009	158096-6	SHOE COMPLETE	1	
010	233480-7	COMPRESSION SPRING 7	1	
011	286275-7	CAP	1	
012	233084-5	COMPRESSION SPRING 6	1	
013	286278-1	CAP	1	
014	158092-4	GEAR HOUSING COMPLETE	1	
015	324716-6	PIN 8	1	
016	324708-5	STOPPER PIN 8	1	
017	265913-4	HEX. SOCKET HEAD BOLT M5X8	1	
018	213512-6	O RING 39	1	
019	211021-9	BALL BEARING 607LLB	1	
020	961052-5	RETAINING RING S-12	1	
021	226637-7	HELICAL GEAR 39	1	
022	257010-0	RING 12	1	
023	318088-9	BEARING BOX	1	
024	211129-9	BALL BEARING 6201DDW	1	
025	324707-7	SPINDLE	1	
026	285689-7	BEARING RETAINER 55	1	
027	911221-8	PAN HEAD SCREW M5X16	2	
028	419620-3	DUST NOZZLE	1	
029	213460-9	O RING 35	1	
030	233479-2	COMPRESSION SPRING 11	1	
031	419624-5	SPRING HOLDER	1	
032	158095-8	LEVER 20 COMPLETE	1	
033	213021-5	O RING 5	1	
034	324710-8	PIN 8	1	
035	266007-8	TAPPING SCREW BIND PT 3X10	1	
036	253821-1	FLAT WASHER 3	1	
037	419625-3	DEPTH GUIDE	1	
038	231665-9	TORSION SPRING 7	1	
039	419630-0	LOCK LEVER	1	
040	251867-1	SCREW M5X30	1	
041	941101-4	FLAT WASHER 5	1	
042	419623-7	STOPPER BLOCK	1	
043	266034-5	TAPPING SCREW CT 4X16	2	
044	345744-8	NUT PLATE	1	
045	266034-5	TAPPING SCREW CT 4X16	1	
046	419632-6	POSITION PLATE	1	
047	158547-9	BLADE CASE COMPLETE	1	
048	266053-1	TAPPING SCREW 4X35	1	
049	253010-8	FLAT WASHER 6	1	
050	224406-0	INNER FLANGE 35	1	
051	224405-2	OUTER FLANGE 35	1	
052	266403-0	HEX. SOCKET HEAD BOLT M6	1	
053	318084-7	BLADE CASE COVER	1	
054	266034-5	TAPPING SCREW CT 4X16	5	
055	188197-6	HANDLE SET INC. 102	1	
056	265776-8	THUMB SCREW M6X26	1	
057	253111-2	FLAT WASHER 6	1	
058	419596-4	REAR ANGULAR GUIDE	1	
059	318179-6	BASE	1	

SPARE PARTS LIST

PAGE 2

MODEL NO. SP6000

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
060	265995-6	TAPPING SCREW 4X18	2	
061	324731-0	STOPPER PIN	1	
062	252157-5	SQUARE NUT M6	1	
063	266085-8	H.S.SET SCREW(FLAT POINT)M6X10	1	
064	419595-6	FRONT ANGULAR GUIDE	1	
065	419571-0	DIAL 22	1	
066	961017-7	STOP RING E-3	1	
067	266085-8	H.S.SET SCREW(FLAT POINT)M6X10	2	
068	265995-6	TAPPING SCREW 4X18	2	
069	253111-2	FLAT WASHER 6	1	
070	265776-8	THUMB SCREW M6X26	1	
071	912112-6	COUNTERSUNK HEAD SCREW M4X10	1	
072	345748-0	LOCK WASHER	1	
073	231316-4	COMPRESSION SPRING 7	1	
074	265701-9	SCREW M6X14	1	
075	419627-9	HOLDER	1	
076	265775-0	THUMB SCREW M4X3	1	
077	345977-5	PLATE	1	
078	253932-2	WAVE WASHER 10	1	
079	419621-1	SLIDE LEVER	1	
080	265775-0	THUMB SCREW M4X3	1	
081	419627-9	HOLDER	1	
082	231316-4	COMPRESSION SPRING 7	1	
083	265701-9	SCREW M6X14	1	
084	922232-8	HEX. SOCKET HEAD BOLT M5X20	1	
085	324709-3	LOCK PIN 8	1	
086	233267-7	COMPRESSION SPRING 7	1	
087	419631-8	LOCK PLATE	1	
088	687052-4	STRAIN RELIEF	1	
089	265995-6	TAPPING SCREW 4X18	2	
090	631729-3	CONTROLLER	1	
091	213261-5	O RING 17	1	
092	418905-4	DIAL	1	
094	419622-9	SWITCH LEVER	1	
095	651922-3	SWITCH TG71B	1	
096	345745-6	LINK PLATE	1	
097	419629-5	LOCK OFF BUTTON	1	
098	233089-5	COMPRESSION SPRING 12	1	
099	265995-6	TAPPING SCREW 4X18	6	
100	911273-9	PAN HEAD SCREW M5X50	1	
101	862913-1	SP6000 NAME PLATE	1	
102	188197-6	HANDLE SET INC. 55	1	
103	666216-3	POWER SUPPLY CORD 1.5-2-2.5	1	
104	682503-2	CORD GUARD 8-90	1	
105	419626-1	BAFFLE PLATE	1	
106	266044-2	TAPPING SCREW 5X60	2	
107	525743-8	FIELD ASS'Y 220-240V	1	
108	158094-0	MOTOR HOUSING COMPLETE	1	
109	911273-9	PAN HEAD SCREW M5X50	4	
110	B-80151	CARBON BRUSH SET CB-303A	1	
111	643750-0	BRUSH HOLDER CAP	2	
112	267781-1	WAVE WASHER 7	1	
113	231372-4	COMPRESSION SPRING 5	1	
115	421479-6	RUBBER RING 19	1	
116	424047-4	PACKING	1	
117	424050-5	SPONGE	1	
118	443137-4	FELT	1	
A01	B-07353	TCT SAW BLADE 165X20X48T	1	
A02	783203-8	HEX. WRENCH 5	1	
A03	165447-6	SUB BASE	1	

SERVICE DRAWING

PAGE 1

MODEL NO. SP6000

